

## **IGNITION MODULE for BMW BOXER TWINS**

### **Installation**

1. Clean the heat sink surface where the module will be mounted. This is essential for good thermal contact.
2. Apply a thin coat of the enclosed thermal grease to the metal surface of the module.
3. Attach the module to the heat sink using the original screws and torque to **8-12 in/lbs. Do not over tighten.**
4. Replace the electrical connector.